

Selling silence

Installation instruction - Dezibel golvskärm

Start by assembling the base. Use the illustration below. It consists of four parts: Base plate, white inner pole, square tray and wooden pole. First screw the white inner post in the footboard with the supplied black screws. The footplate has recessed hole on the underside.

Then take the wooden pole and place it on the inner post, fasten it with the help of the white tray and supplied black screw.

Now, the foot and the screen be put together. Place the screen into the jaws of the wooden pole and remove the supplied threaded pins and through the post and the screen. Screwed with a nut hat on each side.

The post has a certain sviktmån to adapt to the different thicknesses of fabric. It is possible to tighten the nuts quite firmly to get a good result.



