

# Zilenzio

## Assembly instructions

### Skog

1. Attach the white inner post to the footplate with the accompanying black screws.
2. Tread the hollowed-out wooden post over the white inner post and fasten with the square washer. Use the accompanying screws to fasten the washer.
3. Place the screen in the wooden post opening. Push the accompanying pins into the holes in the post and screen. Attach using a nut cap on each side. Tighten both screws securely to ensure that the screen is seated firmly in the post.

